

MICROMODULE SWITCH DOUBLE

QUICK INSTALLATION GUIDE
v1.4

TRADEMARKS

Zipato and the Zipato logo are registered Trademarks. All other product names mentioned herein may be trademarks or registered trademarks of their respective companies.

NOTICE

Although Zipato has attempted to ensure the accuracy of the content of this manual, it is possible that this document may contain technical inaccuracies, typographical, or other errors. Zipato assumes no liability for any error in this publication, and for damages, whether direct, indirect, incidental, and consequential or otherwise, that may result from such error, including, but not limited to loss of data or profits. Zipato provides this publication "as is" without warranty of any kind, either express or implied, including, but not limited to implied warranties of merchantability or fitness for a particular purpose. The published information in the manual is subject to change without notice. Zipato reserves the right to make changes in the product design, layout, and driver revisions without notification to its users. This version of the Installation guide supersedes all previous versions.

ELECTROMAGNETIC COMPATIBILITY

When operated according to manufacturer instructions, the product complies with all applicable CE harmonised standards from EMC Directive 2004/108/EC and Part 15 of the FCC Rules. The connections conducting HF signals must not be damaged or altered in any way by the user.

TAKE CARE OF YOUR SAFETY

Display extreme caution when using ladders or steps, please follow manufacturer's instructions. Be careful when using hand and power tools and follow the manufacturer's guidelines when using them. Take care that the correct tools are used. Wear goggles or protective clothing where required.

DANGER

RISK OF ELECTROCUTION

All work on the device should only be carried out by trained and skilled electricians. Observe the country-specific regulations.

DANGER

RISK OF FATAL INJURY FROM ELECTRIC CURRENT.

The device has no basic insulation and must therefore be installed in a way that protects against accidental contact.

DANGER

RISK OF FATAL INJURY FROM ELECTRIC CURRENT.

When installing a wall plate, the distance between the cover's fixing brackets or screws and the connections of the flush-mounted MicroModule Switch Double must be at least 4 mm once installed. If the distance is less than 4 mm, a deeper installation box must be used. The fixing brackets or screws of the cover must not press against the housing. Only insulated tools may be used for operation on the device, e.g. an insulated phase tester.

CAUTION

The connected devices and the flush-mounted receiver can become damaged if devices are operated that do not correspond to the technical specifications [see technical data].


INTRODUCTION

Micromodule Switch Double is a transceiver which is a Z-Wave Plus enabled device and is fully compatible with any Z-Wave enabled network. Mini size design allow the module to be easily hidden into the wall box which is good for the house decoration.

There are many kinds of application for using the module to switch AC power ON and OFF, one of which is the light control. The new smart relay calibration technology can reduce the inrush current caused by the load and let the module work perfectly with many kinds of light like incandescent, fluorescent and LED light. This Micromodule is able to detect Instant power wattage and overload wattage (current 7.5A) of connected light or appliances. When detecting overload state, the switch will be disabled and its ON/OFF button will be locked during which LED will flash repeatedly. Unplugging and reconnecting the Module will reset its overload condition to normal status.

OVERVIEW

FIGURE 1
Dimensions (unit: mm)



PACKAGE CONTENT

1PC	Micromodule Switch Double
1PC	Quick Installation Guide

FEATURES

- Slim, compact remote Z-Wave module switches and controls all parameters of power that your electrical appliances consume.
- Voltage, Current, Power factor, Instant power wattage and Accumulated power report
- Resistive load 1500W x 2
- Zero-crossing switch
- Higher output power enhances communication range(+2.5dBm output power compared to -2.5dBm 300 series)
- New Z-Wave 500 series chip supports multichannel operation and higher data rates (9.6/40/100kbps)
- Overload protection
- Auto reports wattage when variation exceeds 5%
- Very low power power consumption
- Over-the-air firmware update
- Easy installation

SPECIFICATION


TECHNICAL SPECIFICATION

PROTOCOL	Z-Wave Plus
OPERATING VOLTAGE:	100-240VAC
MAXIMUM LOAD	6.5A(230VAC/120VAC) (Resistive load)
OPERATING TEMPERATURE	0°C ~ 40°C
RANGE	Minimum 30m indoor / 70m outdoor
WEIGHT	39g
DIMENSIONS	46mm x 15mm x 39mm
PACKAGE WEIGHT	68g
PACKAGE DIMENSIONS	67mm x 22mm x 162mm
REGULATIONS	EMC 2004/108/EC, R&TTE 1995/5/EC, LVD 2006/95/EC, FCC PART 15
WARRANTY	1 year

MODELS AND FREQUENCIES

EUROPEAN UNION - EU version	ph-pan04.eu / 868.42 MHz
UNITED STATES - US version	ph-pan04.us / 908.42MHz
RUSSIA - RU version	ph-pan04.ru / 869.02MHz
ISRAEL - IS version	ph-pan04.is / 916.02MHz
AUSTRALIA - AU version	ph-pan04.au / 921.42MHz
INDIA - IN version	ph-pan04.in / 865.20MHz


INSTALLATION AND OPERATION



- Put the in wall Micromodule into a wall box and connect the AC power wire L,N to Micromodule's connector L, N.
- Connect the Micromodule to the switch as shown in picture
- To manually turn ON to the Micromodule, press and release the On/Off button. The LED will light ON for 1 second, and the load plugged into the Micromodule will also turn ON.
- To manually turn OFF the Micromodule, simply press and release the On/Off button. The LED will light ON for 1 second and the load plugged into the Micromodule will turn OFF

APPLICATION

- In Wall Switch 2 relay; 1A Type



CHOOSING A SUITABLE LOCATION

- Do not locate the Micromodule facing direct sunlight, humid or dusty place.
- The suitable ambient temperature is 0°C-40°C.
- Do not locate the Micromodule where exists combustible substances or any source of heat, e.g. fires, radiators, boiler etc.
- After putting it into use, Micromodule's casing can become little hot on touch which is normal operation.

LED INDICATION

State Type	LED Indication
Normal	Whatever we switch On/Off on the Micromodule by S1 S2 or On/Off button or RF command, the LED will light up for 1 second.
No node ID	Under normal operation, when the Micromodule has not been allocated a node ID, the LED flashes on and off alternately at 2-second intervals. By pressing S1 S2 or On/Off button, it will stop flashing temporarily.
Learning	When Micromodule is in learning mode, LED flashes on and off alternately and repeatedly at 0.5 second intervals.
Overload	When overload state occurs, the Micromodule is disabled of which LED flashes on and off alternately at 0.2 second intervals. Overload state can be cleared by disconnect and reconnect the Micromodule to the main power.

ADDING TO Z-WAVE NETWORK

In the front casing, there is an on/off button with LED indicator below which is used to toggle Micromodule on and off or carry out inclusion, exclusion, reset or association. When first power is applied, LED repeatedly flashes in 0.5-second intervals. It implies that it has not been assigned a node ID and starts auto inclusion.

AUTO INCLUSION

The function of auto inclusion will be executed as long as the in wall Micromodule does not have Node ID and is connected to main power. **Note:** Auto inclusion timeout is 2 minutes during which the node information of explorer frame will be emitted once every several seconds. Unlike "inclusion" function as shown in the table below, auto inclusion doesn't require pressing on/off buttons on the Micromodule.

The table below lists an operation summary of basic Z-Wave functions. Please refer to the instructions for your Z-Wave Primary

Controller to access the Setup function, and to include/exclude/associate devices.

Function	Description	LED Indication
No node ID	The Z-Wave Controller does not allocate a node ID to the Micromodule.	2-second on, 2-second off
Inclusion	Have Z-Wave Controller entered inclusion mode by following the instructions provided by the controller manufacturer.	One press one flash
	Pressing INCLUDE_BUTTON threetimes within 2 seconds will enter inclusion mode.	
Exclusion	Have Z-Wave Controller entered exclusion mode by following the instructions provided by the controller manufacturer.	One press one flash
	Pressing INCLUDE_BUTTON three times within 2 seconds will enter exclusion mode.	
	Node ID has been excluded.	0,5-second on, 0,5-second off
Reset [Use this procedure only in the event that the primary controller is lost or otherwise inoperable.]	Pressing INCLUDE_BUTTON three times within 2 seconds will enter inclusion mode.	One press one flash
	Within 1 second, press On/Off button again for 5 seconds until LED is off. IDs are excluded.	0,5-second on, 0,5-second off
Including a node ID allocated by Z-Wave Controller means inclusion. Excluding a node ID allocated by Z-Wave Controller means exclusion. Failed or success in including/excluding the node ID can be viewed from the Z-Wave Controller.		

Sometimes, people find it hard to execute exclusion or inclusion especially when Micromodule is already installed in a wall box. To solve this issue, Micromodule supports a special feature that can use S1 or S2 to execute "exclusion, inclusion, Reset or Association" during first 3 minutes when connected to the main power for first time.

PROGRAMMING

1 | BASIC COMMAND CLASS / BINARY SWITCH COMMAND CLASS

Micromodule will respond to BASIC and BINARY commands that are part of the Z-Wave system.

1.1 | BASIC_GET / BINARY_SWITCH_GET

Since the switch have two relay, the Micromodule will report its On/Off state to the Controller by setting Configuration parameter 3.

Configuration parameter 3=1	Report ON when relay 1 ON Report OFF when relay 1 OFF
Configuration parameter 3=2	Report ON when relay 2 ON Report OFF when relay 2 OFF
Configuration parameter 3=3 (default)	Report ON when either relay 1 ON or relay 2 ON Report OFF when both relay 1 and relay 2 OFF
Basic Get Command: [Command Class Basic, Basic Get]	
Basic Report Command: Report OFF: [Command Class Basic, Basic Report, Value = 0(0x00)] Report ON: [Command Class Basic, Basic Report, Value = {255}(0xFF)]	

Binary Switch Get Command: [Command Class Switch Binary, Switch Binary Get]	
Binary Switch Report Command: Report OFF: [Command Class Switch Binary, Switch Binary Report, Value =0(0x00)] Report ON: [Command Class Switch Binary, Switch Binary Report, Value = {255}(0xFF)]	

1.2 | BASIC_SET / SWITCH_BINARY_SET

Since the switch have two relays, the load attached to the Micromodule will turn on or off upon receipt of the following commands from a Z-Wave Controller by setting Configuration parameter 3.

Configuration parameter 3=1	Switch ON and OFF of relay 1
Configuration parameter 3=2	Switch ON and OFF of relay 2
Configuration parameter 3=3 (default)	Switch ON and OFF both relay 1 and relay 2

[Command Class Basic, Basic Set, Value = 1-99, 255(0xFF)]: the load attached to the Micromodule turns on.

[Command Class Basic, Basic Set, Value = 0(0x00)]: the load attached to the Switch turns off.

[Command Class Switch Binary, Switch Binary Set, Value = 1-99, 255(0xFF)]: the load attached to the Switch turns on.

[Command Class Switch Binary, Switch Binary Set, Value = 0(0x00)]: the load attached to the Micromodule turns off.

2 | Z-WAVE'S GROUPS (ASSOCIATION COMMAND CLASS VERSION 2)

Micromodule can be set to send reports in order to control associated Z-Wave devices. It supports 3 association groups which every group has one node support. Group1-Group3 support SWITCH_BINARY_REPORT.

METER_REPORT_COMMAND_V3

For group 1, Micromodule will report (1) ON/OFF status of Relay1 and Relay2 (2) Instant Power Consumption [Watt] of Relay1 and Relay2 (3) Accumulated Power Consumption [KWh] of Relay1 and Relay2 to Z-Wave Controller.

For group 2, Micromodule will report (1) ON/OFF status of Relay1 (2) Instant Power Consumption [Watt] of Relay1 (3) Accumulated Power Consumption [KWh] of Relay1 to Z-Wave Controller.

For group 3, Micromodule will report (1) ON/OFF status of Relay2 (2) Instant Power Consumption [Watt] of Relay2 (3) Accumulated Power Consumption [KWh] of Relay2 to Z-Wave Controller.

2.1 | Auto report to Grouping 1 -3 [Maximum Node 1]

2.1.1 | On/Off Event Report

When "on" or "off" state has been changed by pressing S1, S2 or on/off button, it will send Binary Switch Report to the nodes of Group1-3.

Binary Switch Report:

ON: [Command Class Switch Binary, Switch Binary Report, Value={255}(0xFF)]
OFF: [Command Class Switch Binary, Switch Binary Report, Value=0(0x00)]

2.1.2 | INSTANT POWER CONSUMPTION VARY OVER 5% REPORT
When the power consumption of load vary over 5%, it will send Meter report to the nodes of Group

[Command Class Meter, Meter Report, Rate Type = 0x01, Meter Type = 0x01, Precision = 1, Scale = 0x02, Size = 4, Meter Value[W]]

2.1.3 | OVERLOAD ALARM REPORT COMMAND

When Micromodule detects the overload, it will send Alarm Report to the corresponding Group

The content of Alarm Report:

Alarm report command: [Command_Class_Alarm, Alarm_Report, Alarm Type = 0x08, Alarm Level = 0xFF]

2.2 | RESPONSE TO METER GET COMMAND

Micromodule will report its (1) Instant Power Consumption (Watt) or (2) accumulated power consumption(KWH) or (3) AC load Voltage (V) or (4) AC load current (I) (5) load power factor (PF) to Z-Wave Controller after receive the Meter Get Command from Z-Wave Controller.

2.2.1 | Instant Power Consumption [Watt] of Micromodule
When receiving Meter Get Command, it will report Meter Report Command to the node asked.

Meter Get Command: [Command Class Meter, Meter Get, Scale =0x02(W)]

[Command Class Meter, Meter Report, Rate Type = 0x01, Meter Type = 0x01, Precision = 1, Scale = 0x02, Size = 4, Meter Value[W]]

Example:

Meter Value 1 = 0x00 (W)
Meter Value 2 = 0x00 (W)
Meter Value 3 = 0x03 (W)
Meter Value 4 = 0xEA (W)
Meter(W) = Meter Value 3 *256 + Meter Value 4 = 100.2W

2.2.2 | Accumulated Power Consumption [KWh/h]

When receiving Meter Get Command, it will report Meter Report Command to the node asked.

Meter Get Command: [Command Class Meter, Meter Get, Scale = 0x00 KW/h]

[Command Class Meter, Meter Report, Rate Type = 0x01, Meter Type =0x01, Precision = 2, Scale = 0x00, Size = 4, Meter Value [KWh]]

Example:

Scale = 0x00 [KWh]
Precision = 2
Size = 4 Bytes [KWh/h]
Meter Value 1 = 0x00(KWh)
Meter Value 2 = 0x01(KWh)
Meter Value 3 = 0x38(KWh)
Meter Value 4 = 0xA3(KWh)

Accumulated power consumption (KW/h) = (Meter Value 2*65536) + (Meter Value 3*256) + (Meter Value 4) = 800.35 [KW/h]

2.2.3 | CLEARING ACCUMULATED POWER CONSUMPTION

If you want to reset accumulated power consumption, you can use Meter Reset Command to clear it.

Meter Reset Command: [Command Class Meter, Meter Reset]

2.2.4 | AC LOAD VOLTAGE (V)

When receiving Meter Get Command, it will report Meter Report Command to the requested node. Meter Get Command: [Command Class Meter, Meter Get, Scale =0x04(V)]

Meter Report Command:
[Command Class Meter, Meter Report, Rate Type = 0x01, Meter Type = 0x01, Precision = 1, Scale = 0x04, Size = 2, Meter Value[V]]

Example:

Scale = 0x04 (V)

Precision = 1

Size = 2 (2 Bytes of V)
Meter Value 1 = 0x09(V)
Meter Value 2 = 0x01(V)
AC load Voltage = (Meter Value 1*256) +(Meter Value 2) = 230.5 (V)

2.2.5 | AC LOAD CURRENT (I)

When receiving Meter Get Command, it will report Meter Report Command to the requested node.

Meter Get Command: [Command Class Meter, Meter Get, Scale =0x05(I)]

Meter Report Command:
[Command Class Meter, Meter Report, Rate Type = 0x01, Meter Type = 0x01, Precision = 2, Scale = 0x05, Size = 2, Meter Value[I]]

Example:

Precision = 2
Size = 2 (2 Bytes of I)
Meter Value 1 = 0x01(I)
Meter Value 2 = 0x21(I)
AC load current = (Meter Value 1*256) +(Meter Value 2) = 2.89 (A)

2.2.6 | LOAD POWER FACTOR (PF)

When receiving Meter Get Command, it will report Meter Report Command to the requested node.

Meter Get Command: [Command Class Meter, Meter Get, Scale =0x06(PF)]

Meter Report Command:
[Command Class Meter, Meter Report, Rate Type = 0x01, Meter Type = 0x01, Precision = 2, Scale = 0x06, Size = 1 Bytes, Meter Value[PF]]

Example:

Scale = 0x06 (PF)
Precision = 2
Size = 1 (1 Byte of PF)
Meter Value 1 = 0x63(PF) (It means that the load power factor is 0.99)

2.3 | MULTI CHANNEL COMMAND CLASS VERSION 3

Micromodule also supports multi channel command class(version 3), which includes BINARY_SWITCH_GET, BINARY_SWITCH_SET, METER_SUPPORTED_GET, METER_RESET, METER_GET
You may control or get report from 3 endpoints of Micromodule.

2.3.1 | BINARY_SWITCH_GET

You may get the ON/OFF state from every endpoint, when endpoint set to 1, Micromodule will reply state of Relay1. If endpoint set to 2, Micromodule will reply state of Relay2. If endpoint set to 3, Micromodule will reply ON (0xFF) when either Relay 1 or Relay2 is ON, report OFF (0x00) when both Relay 1 and Relay2 are OFF.
Below example shows a source endpoint 5 send a Get command to Micromodule endpoint 3:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x05
- this is the endpoint of command owner here we assume endpoint is 5, if the owner doesn't support multi Channel this value will be 0
- [Bit Address+Destination End Point = 0x03]
- [Bit Address=0, Destination End Point range from 1-3]
- Command Class = 0x25
- [Command_Class_Switch_Binary = 0x25]
- Command =0x02
- [Switch_Binary_Get = 0x02]

Below is the example show Micromodule report to last command:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x03
- Since the endpoint is 3 so Micromodule will reply ON(0xFF)

either Relay 1 or Relay2 is ON, report OFF (0x00 when both Relay 1 and Relay2 OFF

- [Bit Address+Destination End Point = 0x05]
- [Bit Address=0; Destination End Point]
- Command Class = 0x25
- [Command_Class_Switch_Binary = 0x25]
- Command =0x03
- [Switch_Binary_Report = 0x3]
- Parameter 1 = 0xFF
- [ON=0xFF, OFF=0x00]

2.3.2 | BINARY_SWITCH_SET

By using BINARY_SWITCH_SET Command of Multi Channel Command Class Encapsulate Command, you can switch both Relay1 and Relay2 ON/OFF by setting endpoint to 1 or switch Relay1 ON/OFF by setting endpoint to 2 or switch Relay2 ON/OFF by setting endpoint to 3. **Below command example shows switching off relay1 of the Micromodule:**

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x01
- this is the endpoint of command owner, here we assume endpoint is 1, if the owner doesn't support multi Channel this value will be 0
- [Bit Address+Destination End Point = 0x01]
- [Bit Address=0; Destination End Point range1-3]
- Command Class = 0x25
- [Command_Class_Switch_Binary = 0x25]
- Command =0x01
- [Switch_Binary_Set = 0x01]
- Parameter 1 = 0x00
- [ON=0xFF, OFF=0x00]

2.3.3 | METER_SUPPORTED_GET

This command is to ask the endpoint of Switch what kind of meter data can be reported. **Below example shows how to get the meter report type:**

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x01
- this is the endpoint of command owner here we assume endpoint is 1, if the owner doesn't support multi Channel this value will be 0
- [Bit Address+Destination End Point = 0x03]
- [Bit Address=0; Destination End Point range1-3]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x03
- [Meter_Supported_Get = 0x03]

Below is the example show Switch report to last command:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x03
- [Bit Address+Destination End Point = 0x01]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x04
- [Meter_Supported_Report = 0x04]
- Parameter 1 = 0x81
- [Meter Reset =1, Meter Type=0x01]
- Parameter 2 = 0x75
- [Scale Supported = KWh+W+V+A+Power Factor = 0x75]

2.3.4 | METER_RESET

This command is to reset the Accumulated Power Consumption (KWh) to 0. **The example show how to reset the KWh:**

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x03
- this is the endpoint of command owner, here we assume endpoint is 3, if the owner doesn't support multi Channel this value will be 0

- [Bit Address+Destination End Point = 0x01]
- [Bit Address=0; Destination End Point range1-3]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x05
- [Meter_Reset = 0x05]

2.3.5 | METER_GET

Using meter get command to get the KWH,W,V,I,PF from endpoint of Switch. **Example:**

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x05
- this is the endpoint of command owner, here we assume endpoint is 5, if the owner doesn't support multi Channel this value will be 0
- [Bit Address+Destination End Point = 0x03]
- [Bit Address=0; Destination End Point range1-3]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x01
- [Meter_Get = 0x01]
- Parameter 1 = 0x00
- [Scale = KWH = 0x00]

Accumulated power consumption (KWH) Report example:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x03
- [Meter report = Endpoint3]
- [Bit Address+Destination End Point = 0x05]
- [Bit Address=0; Destination End Point = command owner Endpoint value]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x02
- [Meter_Report = 0x02]
- Parameter 1 = 0x21
- [Scale Bit2 = 0, Rate Type = 0x01, Meter Type=0x01]
- Parameter 2 = 0x44
- [Precision = 2, Scale Bit1Bit0 = 0, Size = 4]
- Parameter 3; 4 = 0x00
- Accumulated Power Consumption = 0x000005FD = 15.33 KWh
- Parameter 5 = 0x05
- Parameter 6 = 0xFD

Get Instant Power Consumption (Watt) from endpoint.

METER_GET example:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x05
- this is the endpoint of command owner, here we assume endpoint is 5, if the owner doesn't support multi Channel this value will be 0
- [Bit Address+Destination End Point = 0x03]
- [Bit Address=0; Destination End Point range 1-3]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x01
- [Meter_Get = 0x01]
- Parameter 1 = 0x10
- [Scale = W = 0x02]

Micromodule Power Consumption (W) Report example:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x03
- [Meter report = Endpoint3]
- [Bit Address+Destination End Point = 0x05]
- [Bit Address=0; Destination End Point = command owner Endpoint value]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]

- Command =0x02
- [Meter_Report = 0x02]
- Parameter 1 = 0x21
- [Scale Bit2 = 0, Rate Type = 0x01, Meter Type=0x01]
- Parameter 2 = 0x34
- [Precision = 1, Scale Bit1Bit0 = 0x02, Size = 4]
- Parameter 3; 4 = 0x00
- Instant Power Consumption = 0x000003EA = 100.2W
- Parameter 5 = 0x03
- Parameter 6 = 0xEA

Get load voltage V from endpoint

METER_GET example:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x05
- this is the endpoint of command owner, here we assume endpoint is 5, if the owner doesn't support multi Channel this value will be 0
- [Bit Address+Destination End Point = 0x03]
- [Bit Address=0; Destination End Point range1-3]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x01
- [Meter_Get = 0x01]
- Parameter 1 = 0x20
- [Scale = V = 0x04]

Micromodule AC load Voltage example:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x03
- [Meter report = Endpoint3]
- [Bit Address+Destination End Point = 0x05]
- [Bit Address=0; Destination End Point = command owner Endpoint value]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x02
- [Meter_Report=0x02]
- Parameter 1 = 0xA1
- [Scale Bit2 = 1, Rate Type = 0x01, Meter Type=0x01]
- Parameter 2 = 0x22
- [Precision = 1, Scale Bit1Bit0 = 0x00, Size = 2]
- Parameter 3 = 0x09
- Voltage = 0x0910 = 232.0V
- Parameter 4 = 0x10

Get load current I from endpoint

METER_GET example:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x05
- this is the endpoint of command owner, here we assume endpoint is 5, if the owner doesn't support multi Channel this value will be 0
- [Bit Address+Destination End Point = 0x03]
- [Bit Address=0; Destination End Point range1-3]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x01
- [Meter_Get = 0x01]
- Parameter 1 = 0x28
- [Scale = A = 0x05]

Micromodule AC load current (I) example:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x03
- [Meter report = Endpoint3]
- [Bit Address+Destination End Point = 0x05]
- [Bit Address=0; Destination End Point = command owner Endpoint value]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x02

- [Meter_Report = 0x02]
- Parameter 1 = 0xA1
- [Scale Bit2 = 1, Rate Type = 0x01, Meter Type=0x01]
- Parameter 2 = 0x4A
- [Precision = 2, Scale Bit1Bit0 = 0x01, Size = 2]
- Parameter 3 = 0x00
- Current = 0x002B = 0.43A
- Parameter 4 = 0x2B

Get power factor PF from endpoint

Meter_GET example:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x05
- this is the endpoint of command owner, here we assume endpoint is 5, if the owner doesn't support multi Channel this value will be 0
- [Bit Address+Destination End Point = 0x03]
- [Bit Address=0; Destination End Point range1-3]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x01
- [Meter_Get = 0x01]
- Parameter 1 = 0x30
- [Scale = PF = 0x06]

Micromodule power factor report example:

- COMMAND_CLASS_MULTI_CHANNEL
- MULTI_CHANNEL_CMD_ENCAP
- Source End Point = 0x03
- [Meter report = Endpoint3]
- [Bit Address+Destination End Point = 0x05]
- [Bit Address=0; Destination End Point = command owner Endpoint value]
- Command Class = 0x32
- [Command_Class_Meter_V3 = 0x32]
- Command =0x02
- [Meter_Report = 0x02]
- Parameter 1 = 0xA1
- [Scale Bit2 = 1, Rate Type = 0x01, Meter Type=0x01]
- Parameter 2 = 0x51
- [Precision = 2, Scale Bit1Bit0 = 0x10, Size = 1]
- Parameter 3 = 0x63
- Power Factor = 0x63 = 0.99

3 | Z-WAVE'S CONFIGURATION

Configuration Parameter 1		
Function	Size (byte)	Value
Watt Meter Report Period	2	0x01-0x7FFF
Unit	Default	Description
5s	720	5*720s=3600s=1 hour

Configuration Parameter 2		
Function	Size (byte)	Value
KWH Meter Report Period	2	0x01-0x7FFF
Unit	Default	Description
10min	6	6*10min= 1 hour

Configuration Parameter 3		
Function	Size (byte)	Value
Selected End Point	1	1-3
Unit	Default	Description
	1	1: Relay1 2: Relay1 3: Relay1 & Relay2

Configuration Parameter 4		
Function	Size (byte)	Value
Edge or Pulse mode or Edge-Toggle mode	1	1-3
Unit	Default	Description
	1	1: Edge mode 2: Pulse mode 3: Edge-Toggle mode

Configuration Parameter 5		
Function	Size (byte)	Value
Threshold of Watt for Load Caution	2	10-750
Unit	Default	Description
0.01A	750	

Configuration Parameter 6		
Function	Size (byte)	Value
Threshold of KWh for Load Caution	2	1-10000
Unit	Default	Description
1KWh	10000	

Configuration Parameter 7		
Function	Size (byte)	Value
Restore switch state mode	1	0-2
Unit	Default	Description
	1	0: Switch off 1: Last switch state 3: Switch on

Configuration Parameter 8		
Function	Size (byte)	Value
Auto off timer	2	0-0x7FFF
Unit	Default	Description
1s	0	0: Disable auto off function 1-0x7FFF: 1s - 32767s

Configuration Parameter 9		
Function	Size (byte)	Value
RF off command mode	1	0-3
Unit	Default	Description
	0	0: Switch off 1: Ignore 2: Switch toggle 3: Switch on

Configuration Parameter 10		
Function	Size (byte)	Value
Existence of Endpoint3	1	1-2
Unit	Default	Description
	1	1: Endpoint exist 2: No Endpoint3

3.1 | WATT METER REPORT PERIOD

If the setting is configured for 1hour (set value =720), Micromodule

will report its instant power consumption every 1 hour to the node of correspond Group. The maximum interval to report its instant power consumption is 45 hours (5s*32767/3600=45hr).

3.2 | KWH METER REPORT PERIOD

If the setting is configured for 1hour (set value =6), Micromodule will report its Accumulated Power Consumption (KWh/h) every 1 hour to the node of correspond Group. The maximum interval to report its Accumulated Power Consumption (KWh/h) is 227.55 days (10min*32767/1440=227.55 days).

3.3 | SELECTED RELAY

If Micromodule is not using Multi_Channel command class to access the relay of Switch, you may configure the select value to react the Basic Command Class, Binary Switch Command Class or Meter Command Class V3

3.3.1 | SELECTED RELAY1:

Only relay1 can be controlled and report.

3.3.2 | SELECTED RELAY2:

Only relay2 can be controlled and report.

3.3.3 | SELECTED RELAY1 AND RELAY2: DEFAULT SELECT IS 3

Both relay1 and relay2 can be controlled and report.

Set command	Relay state
Basic Set or Binary_Switch_Set ON	Relay1 ON & Relay2 ON
Basic Set or Binary_Switch_Set OFF	Relay1 OFF & Relay2 OFF

Get command	Relay state	Report to command sender
Basic_Get or Binary_Switch_Get	Relay1 ON & Relay2 ON	ON
Basic_Get or Binary_Switch_Get	Relay1 OFF & Relay2 OFF	OFF

Get command	Parameter	Report to command sender
Meter_Get	KWh	Relay1 KWh1+Relay2 KWh2
Meter_Get	Watt	Relay1 W1+Relay2 W2
Meter_Get	Voltage	Relay1 and Relay2 are the same voltage
Meter_Get	Current	Relay1 I1+Relay2 I2
Meter_Get	Power factor PF	Relay1

3.4 | EDGE AND PULSE MODE

Manual switch S1 and S2 can set to Edge mode or Pulse mode or Edge-Toggle mode, default value is Edge mode.

3.4.1 | EDGE MODE

This mode is suitable for the bi stable wall switch that has indicator point on the Micromodule, and the same position corresponds to same state of relay1 and relay2. if the Switch's relay changes the state because of receiving Z-Wave RF command, it may need two switchings (switch on to off or switch off to on) to let relay back to the corresponding state.

3.4.2 | PULSE MODE

this mode is suitable for the toggle type wall switch to swap the state of Relay1 or Relay2.

3.4.3 | EDGE-TOGGLE MODE

This mode is suitable for the normal bi-stable switch, every state change of the wall switch will also swap the state of Relay1 or

Relay2.

3.5 | THRESHOLD OF WATT FOR LOAD CAUTION

This is a warning when the wattage of load over the preset threshold value, If the setting value is 750, when the load wattage of Relay1 or Relay2 over this value, Micromodule will send Watt Meter Report command to the node of correspond Group, the Range of the setting value is from 10 to 750, and the default value is 750.

3.6 | THRESHOLD OF KWH FOR LOAD CAUTION

This is a warning when the KWh of load exceeds preset threshold value, If the setting value is 1000, when the Accumulated Power Consumption of Relay1 or Relay2 exceeds this value, Micromodule will send KWh Meter Report command to the node of corresponding Group, the Range of the setting value is from 10 to 1000, and the default value is 750.

3.7 | RESTORE SWITCH STATE MODE

Whenever the AC power return from lost, Micromodule will restore the switch state which could be SWITCH OFF, LAST SWITCH STATE, SWITCH ON. The default setting is LAST SWITCH STATE.

3.8 | AUTO OFF TIMER

Whenever Micromodule switches to on, the auto off timer begin to count down. After the timer decrease to zero, it will switch off automatically. However if Auto off timer is set as 0, the auto off function will be disabled. The default setting is 0.

3.9 | RF OFF COMMAND MODE

Whenever a switch off command, BASIC_SET, BINARY_SWITCH_SET, SWITCH_ALL_OFF, is received, it could be interpreted as 4 kinds of commands.

3.9.1 | Switch Off: It switches to OFF state. The default setting is Switch Off.

3.9.2 | Ignore: The switch off command will be ignored.

3.9.3 | Switch Toggle: It switches to the inverse of current state.

3.9.4 | Switch On: It switches to ON state

3.10 | EXISTENCE OF ENDPOINT3

Multi-Channel Command is a good way to control relay1 and relay2 of Switch individually. The endpoint3 of Micromodule is related to both relay1 and relay2. In some condition it becomes redundant in Multi-Channel Command Class. When the Existence of Endpoint3 is set as 2, the endpoint3 will be disabled. The default value is 1. Endpoint1 and Endpoint2 are fixed, only Endpoint3 is dynamic.

4 | PROTECTION COMMAND CLASSES

Micromodule supports Protection Command Class version 2, it can protect the switch against unintentional control by e.g. a child. And it can also protect the switch from being turned off by setting it in "No RF Control" state.

After being set to "Protection by sequence" state, any intentional pressing of On/Off button or S2/S2 should be held for longer than 1 second, or the switch state will not change. However, the operation of learn function will not change, because learning will not be protected.

Z-WAVE COMMAND CLASSES

- * COMMAND_CLASS_ZWAVEPLUS_INFO
- * COMMAND_CLASS_VERSION_V2
- * COMMAND_CLASS_MANUFACTURER_SPECIFIC_V2
- * COMMAND_CLASS_DEVICE_RESET_LOCALLY
- * COMMAND_CLASS_ASSOCIATION_V2
- * COMMAND_CLASS_ASSOCIATION_GRP_INFO
- * COMMAND_CLASS_POWERLEVEL
- * COMMAND_CLASS_SWITCH_BINARY
- * COMMAND_CLASS_BASIC
- * COMMAND_CLASS_SWITCH_ALL

- * COMMAND_CLASS_ALARM
- * COMMAND_CLASS_SCENE_ACTIVATION
- * COMMAND_CLASS_SCENE_ACTUATOR_CONF
- * COMMAND_CLASS_PROTECTION
- * COMMAND_CLASS_FIRMWARE_UPDATE_MD_V2
- * COMMAND_CLASS_MULTI_CHANNEL_V3
- * COMMAND_CLASS_METER_V3
- * COMMAND_CLASS_CONFIGURATION

OVER THE AIR FIRMWARE UPDATE

Micromodule is based on 500 series SoC and supports Firmware Update Command Class, so it can receive the updated firmware image sent by controller via the Z-wave RF media. It is a helpful and convenient way to improve some function if needed.

TROUBLESHOOTING

■ Micromodule is not working and LED off

- Cause of Failure:
 - The Switch is not connect to the Main power
- Recommendation:
 - Check power connections
 - Don't open up the Micromodule and send it for repair.
- Micromodule's LED illuminating, but cannot control the ON/OFF switch of the load attached
 - Cause of Failure:
 - Check if the load connect into the Micromodule has its own ON/ OFF switch
 - Recommendation:
 - Set the ON/OFF switch of the load attached to ON
- Micromodule's LED is illuminating, but the Detector cannot control the Switch
 - Cause of Failure:
 - Not carry out association
 - Same frequency interference
 - Recommendation:
 - Carry out association
 - Wait for a while to re-try
- LED keep flashing, but cannot control
 - Cause of Failure:
 - Overload occurs
 - Recommendation:
 - Remove the load attached or check max. load cannot exceed 7.5A

Having trouble installing your new product?

Zipato's website contains the latest user documentation and software updates for Zipato products and services: www.zipato.com

You can also find answers in the Zipato Community at: community.zipato.com

Zipato Support: support@zipato.com

LIMITED PRODUCT WARRANTY

☞ GENERAL TERMS

Nothing in this Limited Product Warranty affects your statutory rights as a consumer.

The Limited Product Warranty set forth below is given by Tri plus grupa d.o.o. [Europe] [herein referred to as "ZIPATO"]. This Limited Product Warranty is only effective upon presentation of the proof of purchase. Upon further request by ZIPATO, this warranty card has to be presented, too.

EXCEPT AS EXPRESSLY SET FORTH IN THIS LIMITED WARRANTY,

ZIPATO MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. ZIPATO EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED IN DURATION TO THE LIMITED WARRANTY PERIOD. TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE CUSTOMER'S SOLE AND EXCLUSIVE REMEDIES AGAINST ZIPATO. THEY DO NOT, HOWEVER, AFFECT OR RESTRICT THE RIGHTS YOU HAVE AGAINST THE BUSINESS YOU BOUGHT A ZIPATO PRODUCT FROM. IN NO EVENT WILL ZIPATO BE LIABLE FOR LOSS OF DATA OR FOR INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. HOWEVER, NOTHING IN THIS AGREEMENT LIMITS ZIPATO'S LIABILITY TO YOU (I) IN THE EVENT OF DEATH OR PERSONAL INJURY TO THE EXTENT RESULTING FROM ZIPATO'S NEGLIGENCE, OR (II) TO THE EXTENT RESULTING FROM ANY FRAUDULENT MISREPRESENTATION ON THE PART OF ZIPATO, OR (III) TO THE EXTENT ARISING UNDER PART 1 OF THE CONSUMER PROTECTION ACT 1987 OF THE UNITED KINGDOM. SOME STATES OR COUNTRIES DO NOT ALLOW: (1) A DISCLAIMER OF IMPLIED WARRANTIES; (2) A LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION; OR (3) LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS. IN SUCH STATES OR COUNTRIES, SOME EXCLUSIONS OR LIMITATIONS OF THIS LIMITED WARRANTY MAY NOT APPLY TO YOU. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS THAT MAY VARY FROM STATE TO STATE OR FROM COUNTRY TO COUNTRY. YOU ARE ADVISED TO CONSULT APPLICABLE STATE OR COUNTRY LAWS FOR A FULL DETERMINATION OF YOUR RIGHTS. This Limited Product Warranty applies to ZIPATO branded hardware products (collectively referred to as "ZIPATO Hardware Products") sold by ZIPATO (Europe), its European subsidiaries, affiliates, authorized resellers, or country distributors (collectively referred to as "ZIPATO Resellers") with this Limited Product Warranty.

The term "ZIPATO Hardware Product" is limited to the hardware components and all its internal components including firmware. The term "ZIPATO Hardware Product" DOES NOT include any software applications or programs.

📍 GEOGRAPHICAL SCOPE OF THE LIMITED PRODUCT WARRANTY

This Limited Product Warranty is applicable to Hardware Products sold by Zipato Resellers in all countries listed at the beginning of this document under the heading "Countries in which this ZIPATO Limited Product Warranty applies". The Limited Product Warranty will be honored in any country where ZIPATO or its authorized service providers offer warranty service subject to the terms and conditions set forth in this Limited Product Warranty. However, warranty service availability and response times may vary from country to country and may also be subject to registration requirements.

📄 LIMITATION OF PRODUCT WARRANTY

ZIPATO warrants that the products described below under normal use are free from material defects in materials and workmanship during the Limited Product Warranty Period set forth below ("Limited Product Warranty Period"), if the product is used and serviced in accordance with the user manual and other documentation provided to the purchaser at the time of purchase (or as amended from time to time).

ZIPATO does not warrant that the products will operate uninterrupted or error-free or that all deficiencies, errors, defects or non-conformities will be corrected.

This warranty shall not apply to problems resulting from: (a) unauthorized alterations or attachments; (b) negligence, abuse or misuse, including failure to operate the product in accordance with specifications or interface requirements; (c) improper handling; (d) failure of goods or services not obtained from ZIPATO or not subject to a then-effective ZIPATO warranty or maintenance agreement; (e) improper use or storage; or (f) fire, water, acts of God or other catastrophic events. This warranty shall also not

apply to any particular product if any ZIPATO serial number has been removed or defaced in any way.

ZIPATO IS NOT RESPONSIBLE FOR DAMAGE THAT OCCURS AS A RESULT OF YOUR FAILURE TO FOLLOW THE INSTRUCTIONS FOR THE ZIPATO HARDWARE PRODUCT.

🕒 LIMITED PRODUCT WARRANTY PERIOD

The Limited Product Warranty Period starts on the date of purchase from ZIPATO. Your dated sales or delivery receipt, showing the date of purchase of the product, is your proof of the purchase date. You may be required to provide proof of purchase as a condition of receiving warranty service. You are entitled to warranty service according to the terms and conditions of this document if a repair to your ZIPATO branded hardware is required within the Limited Product Warranty Period.

[Other than in respect of products for domestic use (in particular those listed in the first and last boxes in the table below), this Limited Product Warranty extends only to the original end user purchaser of this ZIPATO Hardware Product and is not transferable to anyone who obtains ownership of the ZIPATO Hardware Product from the original end-user purchaser.

📊 PRODUCT WARRANTY PERIOD TABLE

PRODUCT TYPE	Micromodule Switch Double
PRODUCT WARRANTY PERIOD	One (1) year

IMPORTANT

The content of "Product Type" listed above is subject to change; please refer to the www.zipato.com for latest update.

🔧 PERFORMANCE OF THE LIMITED PRODUCT WARRANTY

If a product defect occurs, ZIPATO's sole obligation shall be to repair or replace any defective Zipato Hardware Product free of charge provided it is returned to an Authorized ZIPATO Service Centre during the Limited Warranty Period. Such repair or replacement will be rendered by ZIPATO at an Authorized ZIPATO Service Centre. All component parts or hardware products that are replaced under this Limited Product Warranty become the property of ZIPATO. The replacement part or product takes on the remaining Limited Warranty Period of the replaced part or product. The replacement product need not be new or of an identical make, model or part; ZIPATO may in its discretion replace the defective product (or any part thereof) with any reconditioned equivalent (or superior) product in all material respects to the defective product.

WARRANTOR

Tri plus grupa d.o.o.
Banjaveciva 11
10 000 Zagreb
CROATIA

TEL +385 (0)1 4004 404

FAX +385 (0)1 4004 405

DECLARATION OF CONFORMITY



The manufacturer Tri plus grupa d.o.o declares under our sole responsibility that the product:

Marketing model: Micromodule Switch Double

Regulatory model: ph-pan04

Trade/Brand name: Zipato

is in conformity with the Low Voltage Directive 2006/95/EC, EMC Directive 2004/108/EC and R&TTE Directive 1995/5/EC and carries the CE marking accordingly.

The following harmonized standards were applied:

R&TTE (1995/5/EC)

EN 300 220-1: V2.4.1

EN 300 220-2: V2.4.1

EMC (2004/108/EC)

EN 301 489-1: V1.9.2

EN 301 489-3: V1.6.1

LVD (2006/95/EC)

EN 60669-2-1:2004 + A1:2009 + A12:2010 used in conjunction with EN 60669-1:1999 + A1:2002 + A2:2008

Changes or modifications not expressly approved by Tri plus grupa d.o.o. for compliance could void the user's authority to operate the equipment.



THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.

Operation is subject to the following two conditions:

- 1 | this device may not cause harmful interference, and
- 2 | this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Changes or modifications not expressly approved by Zipato for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

♻️ DISPOSING AND RECYCLING YOUR PRODUCT

When it reaches end of life, dispose of the product according to your local environmental laws, guidelines and regulations.



This symbol on the product or packaging means that according to local laws and regulations needs to be disposed of separately from household waste. Once this product has reached the end of its life, please take it to a collection point (recycle facilities) designated by your local authorities, some will accept your product for free or simply drop it off at your Zipato re-seller store. By recycling the product and its packaging in this manner you help to conserve the environment and protect human health. At Zipato, we understand and are committed to reducing any impact our operations and products may have on the environment. To minimize this impact Zipato designs and builds its products to be as environmentally friendly as possible, by using recyclable, low toxic materials in both products and packaging.

© COPYRIGHT

© 2015 Tri plus grupa d.o.o. All Rights Reserved.

No part of this manual may be reproduced or transmitted in any form without the expressed, written permission of Tri plus grupa d.o.o.