

## Lista compatibilità

Marca	Modello
ACCEL	AccelNote CY23
ACCEL	AccelNote CY25
ACER	91.41Q28.002
ACER	91.42S28.002
ACER	91.46W28.002
ACER	91.48R28.003
ACER	ADP-65DB
ACER	Alpha 550 series
ACER	Alpha 550LC
ACER	Alpha 550LV
ACER	Alpha 550XV
ACER	Alpha 551
ACER	Alpha 551VX
ACER	AP.A1003.002
ACER	AP.A1003.003
ACER	AP.T2303.001
ACER	AP.T2303.002
ACER	AP.T3503.002
ACER	Aspire 1200
ACER	Aspire 1200 series
ACER	Aspire 1200X
ACER	Aspire 1200XV
ACER	Aspire 1202
ACER	Aspire 1202X
ACER	Aspire 1203X
ACER	Aspire 1203XC
ACER	Aspire 1203XV
ACER	Aspire 1300
ACER	Aspire 1350
ACER	Aspire 1360
ACER	Aspire 1410
ACER	Aspire 1410
ACER	Aspire 1450
ACER	Aspire 1680

<b>Marca</b>	<b>Modello</b>
ACER	Aspire 1680
ACER	Aspire 1690
ACER	Aspire 2000
ACER	Aspire 2010
ACER	Aspire 2020
ACER	Aspire 300
ACER	Aspire 3000
ACER	Aspire 3010
ACER	Aspire 3020
ACER	Aspire 3030
ACER	Aspire 3500
ACER	Aspire 3600
ACER	Aspire 3610
ACER	Aspire 3628AWXCi
ACER	Aspire 500
ACER	Aspire 5000
ACER	Aspire 5010
ACER	Aspire 5020
ACER	Aspire 5030
ACER	Aspire 5500
ACER	Aspire 5672WML
ACER	Aspire 9100
ACER	Aspire 9500
ACER	Aspire 9500 series
ACER	AT.T2303.001
ACER	Extensa 700
ACER	Extensa 70X
ACER	Extensa 710
ACER	Ferrari 3000
ACER	Ferrari 3200
ACER	Ferrari 3400
ACER	Ferrari 4000 series
ACER	LC.ADT01.001
ACER	LC.ADT01.002
ACER	LC.ADT01.003
ACER	LC.ADT01.004

<b>Marca</b>	<b>Modello</b>
ACER	LC.T2801.006
ACER	N18664
ACER	PA-1650-02
ACER	PA-1750-02
ACER	TravelMate 200
ACER	TravelMate 2000
ACER	TravelMate 210
ACER	TravelMate 219
ACER	TravelMate 220
ACER	TravelMate 230
ACER	TravelMate 2300
ACER	TravelMate 2301
ACER	TravelMate 2302
ACER	TravelMate 2303
ACER	TravelMate 2310
ACER	TravelMate 2350
ACER	TravelMate 2352
ACER	TravelMate 2353
ACER	TravelMate 2400
ACER	TravelMate 2410
ACER	TravelMate 260
ACER	TravelMate 270
ACER	TravelMate 2700
ACER	TravelMate 280
ACER	TravelMate 290
ACER	TravelMate 290E
ACER	TravelMate 292LMi
ACER	TravelMate 3000
ACER	TravelMate 310
ACER	TravelMate 312T
ACER	TravelMate 313
ACER	TravelMate 320 series
ACER	TravelMate 3200
ACER	TravelMate 3200
ACER	TravelMate 3220
ACER	TravelMate 330

<b>Marca</b>	<b>Modello</b>
ACER	TravelMate 340
ACER	TravelMate 350 series
ACER	TravelMate 3500
ACER	TravelMate 360
ACER	TravelMate 370 series
ACER	TravelMate 380
ACER	TravelMate 4000
ACER	TravelMate 4000M
ACER	TravelMate 4001 series
ACER	TravelMate 4002
ACER	TravelMate 4050
ACER	TravelMate 4051
ACER	TravelMate 4052
ACER	TravelMate 4053
ACER	TravelMate 4060
ACER	TravelMate 4100 series
ACER	TravelMate 4150 series
ACER	TravelMate 4500
ACER	TravelMate 4500
ACER	TravelMate 4600
ACER	TravelMate 4650 series
ACER	TravelMate 5000
ACER	TravelMate 505
ACER	TravelMate 505
ACER	TravelMate 506
ACER	TravelMate 506
ACER	TravelMate 506T
ACER	TravelMate 507
ACER	TravelMate 507DX
ACER	TravelMate 507T
ACER	TravelMate 508
ACER	TravelMate 508T
ACER	TravelMate 510
ACER	TravelMate 510 series
ACER	TravelMate 512DX
ACER	TravelMate 512T

<b>Marca</b>	<b>Modello</b>
ACER	TravelMate 513T
ACER	TravelMate 514TVX
ACER	TravelMate 519
ACER	TravelMate 51X
ACER	TravelMate 520
ACER	TravelMate 524TX
ACER	TravelMate 530 series
ACER	TravelMate 5400M
ACER	TravelMate 550 series
ACER	TravelMate 600 series
ACER	TravelMate 6000
ACER	TravelMate 610 series
ACER	TravelMate 620
ACER	TravelMate 630 series
ACER	TravelMate 650 series
ACER	TravelMate 660 series
ACER	TravelMate 7000
ACER	TravelMate 710 series
ACER	TravelMate 720
ACER	TravelMate 730
ACER	TravelMate 740
ACER	TravelMate 800 series
ACER	TravelMate 8000
ACER	TravelMate 8100 series
ACER	TravelMate 8200 series
ACER	TravelMate C100
ACER	TravelMate C110
ACER	TravelMate C200
ACER	TravelMate C300
ACER	TravelMate C310
ACER	TravelMate K-550 series
BRICK COMPUTER	Preceptor 4/5 RocketBrick
CHEM USA	ChemBook 3470
CHEM USA	ChemBook 3830
CHEM USA	ChemBook 3830A
CHEM USA	ChemBook 4025

<b>Marca</b>	<b>Modello</b>
CHEM USA	ChemBook 4027
COMPAQ	101898-001
COMPAQ	Presario 300
COMPAQ	Presario 305
COMPAQ	Presario 306
DETEL	CY25
DIABLO	Dive DV30
ERGO	RocketBrick CY23
ERGO	RocketBrick N30N3
FOSA	30N3
FOSA	30N3L
FOSA	CY20
FOSA	CY23
FOSA	CY25
FOSA	CY27
FOSA	N340S2
FOSA	N340S8
FREEDOM	CY27
FUJITSU	Amilo A series
FUJITSU	Amilo A1650
FUJITSU	Amilo A1655G
FUJITSU	Amilo A1667EX
FUJITSU	Amilo A1667G
FUJITSU	Amilo A3667G
FUJITSU	Amilo D5100
FUJITSU	Amilo D5500
FUJITSU	Amilo D6100
FUJITSU	Amilo D6500
FUJITSU	Amilo D7100
FUJITSU	Amilo D7500 series
FUJITSU	LifeBook 30N3
GATEWAY	104365
GATEWAY	104485
GATEWAY	6500920
GATEWAY	ACE83-110114-7000
GATEWAY	ACE83-110128-0200

<b>Marca</b>	<b>Modello</b>
GATEWAY	M275R
GATEWAY	M320
GATEWAY	M500
GATEWAY	M505
GATEWAY	Retail 4000
GEO MICRO	HL-30
GEO MICRO	HL-31
HITACHI	Flora 200
HITACHI	Flora 20NV
HITACHI	Flora 270
HITACHI	Flora 270GX
HYPERDATA	2500
HYPERDATA	2700
HYPERDATA	CY23
HYPERDATA	CY25
HYPERDATA	CY27
HYPERDATA	N38W2
JEWEL	Brillant 2750
JEWEL	CY23
LAM SYSTEMS	LAMTop CY23
LAM SYSTEMS	LAMTop CY25
LAM SYSTEMS	LAMTop CY27
MEDIABOOK	30N3
MEDIABOOK	ACY23
MEDIABOOK	e-751i
MEDION	MD6179
MICRO EXPRESS	CY25-C
MICRO EXPRESS	CY25-V
MICRO EXPRESS	NP 4333
MICRO FLEX TECH	FlexNote 30N
MICRO FLEX TECH	FlexNote 30N3
MICRO FLEX TECH	FlrxNote CY23
MICRO FLEX TECH	FlrxNote CY25
MICRO FLEX TECH	FlrxNote CY27
MICRON (MPC)	Transport NX
PROGEN TECH	P86

<b>Marca</b>	<b>Modello</b>
SACA TECH	SACANote CY27
SONY ERICSSON	K-550C
SONY ERICSSON	K-550I
SONY ERICSSON	K-550IM